

# CANVAS<sup>TM/MC</sup>


## SANDBANKS

5-PIECE FIRE TABLE SET—STATIONARY ROCKING  
CHAIRS WITH CUSHIONS

---

**PRODUCT NO. RMS633G**

**MODEL NO. 088-2217-6**



### ASSEMBLY INSTRUCTIONS

Toll-free: 1-888-670-6684

**IMPORTANT:** Please read this manual carefully before beginning assembly of this product.  
Keep this manual for future reference.

Made in Vietnam

Imported for Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

<b>Important Safety Instructions</b>	<b>3</b>
<b>Parts List</b>	<b>4</b>
<b>Assembly</b>	<b>5</b>
<b>Cleaning and Maintenance</b>	<b>9</b>
<b>Technical Data</b>	<b>9</b>
<b>Warranty</b>	<b>10</b>



Warning! To reduce the risk of serious injury, read the following safety instructions before assembling and using the chair.

















**Caution! Always keep children under close supervision while they are using or are around this product.**

**Never leave children unattended.**

- This product is intended for domestic, outdoor use only.
- The product should be placed on flat, horizontal ground.
- Any assembly or maintenance of the product must be carried out by adults only.
- Arrange necessary manpower when assembling or moving the product.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- Keep children and pets away while setting up the chair.
- Check all of the nuts and bolts periodically for tightness. When required, tighten them again.
- Repairing and replacing parts should be done by a qualified technician.
- Use the correct bolts as indicated. Do not tighten any of the bolts until the chair is completely assembled.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- Children should always be under direct adult supervision while using this product.
- Retain these assembly instructions for future reference.

**IMPORTANT:** Retain for future reference and read carefully.

## 4 PRODUCT NO. RMS633G | MODEL NO. 088-2217-6

<b>1</b> Right Arm - 1 RMS633G-CS01-3		<b>A</b> M6x15 mm Bolt - 4 17C33A0706001YX	
<b>2</b> Left Arm - 1 RMS633G-CS01-2		<b>B</b> M6x30 mm Bolt - 4 17C02A0710002YX	
<b>3</b> Support - 1 RMS633G-CS08-1		<b>C</b> M8x40 mm Bolt - 4 17C01A0814001YX	
<b>4</b> Seat Post - 1 RMS633G-CS14-1-SV01		<b>D</b> M8x45 mm Bolt - 4 17C01A0816071YX	
<b>5</b> Seat Assembly - 1 RMS633G-CS11-1		<b>E</b> D6.5xD13x1.0 mm Washer - 4 17FA05040301-YX	
<b>6</b> Support Frame - 1 RMS633G-CS14-1-SV02		<b>F</b> D8.5xD17x1.6 mm Washer - 12 17FA08060601-YX	
<b>7</b> Back Cushion - 1 61R633GX00001BA		<b>G</b> 50x50x4.5 mm Washer - 2 17EF1201-----23	
<b>8</b> Seat Cushion - 1 61R633GY00001BA		<b>H</b> M8x1.25 mm Jam Nut - 4 17D03A040401-YX	



**CAUTION!**

- Proper placement of your chair is essential.
- Do not place the product underneath electrical lines.
- Keep children away during assembly.
- This product contains small parts which can be swallowed by children.
- Keep fingers away from the places where they can be pinched or trapped.
- Do not attempt to assemble the chair if any parts are missing.

**Let us help you!**


**DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST!**  
**1-888-670-6684**

If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.


**IMPORTANT:** Please read and understand this manual before any assembly. Before beginning assembly of product, make sure that all parts are present. Compare parts with the parts list. If any part is missing, or if you have any questions, contact the service centre at 1-888-670-6684 (toll free).

Place all of the parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure that you understand each step. If you are missing a part, please call our toll-free number for assistance 1-888-670-6684.


Needed for assembly:



Torque Wrench " I " + Hex Screw " II "



Torque Wrench " I " + Hex Screw " III "




2 people

**Step 1**

**Requires: 5, 6, A, and E**

Place the seat assembly **5** onto a non-abrasive surface, such as a carpet, with its underside facing upwards. Fasten the support frame **6** to the seat assembly **5** by using bolts **A** and washers **E**.




**Step 2**

**Requires: 1, 2, 3, and B**

Fasten the support **3** to right arm **1** and left arm **2** by using bolts **B**. Do not tighten the bolts.



Note:

The labels marked "L" and "R" on arms (1 and 2) should coincide with Step 2 to ensure proper assembly.




**Step 3****Requires: 1, 2, 4, C, and F**

Fasten the seat post **4** to the arms **1** and **2** by using bolts **C** and washers **F**.  
Do not tighten the bolts.



**Step 4****Requires: 4 and 5**

Position the back assembly **5** onto the seat post **4**.




**Step 5****Requires: 4, 6, D, F, G, H, I, II, III, and IV**

Fasten the support frame **6** to the seat post **4** by using bolts **D**, washers (**F** and **G**), and jam nuts **H**. Make sure that all of the bolts have been tightened completely. Secure all of the bolts by using wrenches **I**, **II**, **III**, and **IV**.

**Step 6****Requires: 7 and 8**

Place the cushions **7** and **8** onto the chair. Secure the cushions to the chair by using the plastic clamps.





**CAUTION!**

- Check all of the bolts and nuts periodically for tightness, tightening them again as required.
- Disassemble the chair in the reverse order of the assembly steps. Always disassemble the chair completely. A partially disassembled chair is not stable enough to resist wind and bad weather, and therefore can be damaged and/or cause damage.
- Clean the chair with mild soap and water. Rinse thoroughly, and wait until the product is dry before reassembling it.

- Wash frame and wicker parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame or wicker parts.
- The cushions may be washed on the surface only by using mild soap and water or commercial foaming upholstery cleaner if necessary. If washed, rinse well and hang to dry. Do not machine wash or dry.
- We recommend the use of furniture covers when not in use.
- Inspect and tighten all of the bolts and fasteners on a regular basis to ensure proper performance and safety of your chair.
- In order to prolong the life and beauty of your chair, we recommend that it be stored in a dry and protected area during off-season periods.

Dimensions (LxWxH)	31 7/8 x 28 9/16 x 33 7/8"
	81 x 72.5 x 86 cm
Product weight	15.7 kg
	34 lb 10 oz

This CANVAS product carries a three (3) year warranty against defects in workmanship and materials on the frame and 1 year for the remaining parts. Trileaf Distribution agrees to replace a defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

# CANVAS<sup>TM/MC</sup>


## SANDBANKS

ENSEMBLE TABLE À FOYER, 5 PIÈCES—FAUTEUILS  
BERÇANTS AVEC COUSSINS

---

PRODUIT N° RMS633G

MODÈLE N° 088-2217-6



### INSTRUCTIONS D'ASSEMBLAGE

Numéro sans frais : 1 888 670-6684

IMPORTANT : Lisez ce guide attentivement avant de commencer l'assemblage de cet article.  
Conservez-le à des fins de consultation ultérieure.

Fabriqué au Vietnam

Importé par Trileaf Distribution Trifeuil Toronto, Canada 4S 2B8

<b>Importante consignes de sécurité</b>	<b>3</b>
<b>Liste des pièces</b>	<b>4</b>
<b>Assemblage</b>	<b>5</b>
<b>Nettoyage et entretiens</b>	<b>9</b>
<b>Données techniques</b>	<b>9</b>
<b>Garantie</b>	<b>10</b>



Avertissement! Afin de réduire le risque de blessures sérieuses, suivez les consignes de sécurité avant de commencer l'assemblage et l'usage de ce fauteuil.

**Attention! Surveillez toujours les enfants de près lorsqu'ils utilisent ou sont autour de ce fauteuil.**

**Ne les laissez jamais seuls.**


- Ce fauteuil est conçu pour une utilisation domestique à l'extérieur seulement.
- Ce fauteuil doit être installé sur une surface plane.
- Tout assemblage ou entretien de ce fauteuil doit être effectué par des adultes uniquement.
- Assurez-vous du nombre de personnes requis pour assembler ou déplacer ce fauteuil.
- Certaines pièces peuvent contenir des bords tranchants. Portez des gants de protection s'il y a lieu.
- Tenez les enfants et les animaux éloignés au moment d'assembler ce fauteuil.
- Vérifiez les écrous et boulons régulièrement pour vous assurer qu'ils tiennent bien. Resserrez-les au besoin.
- La réparation et le remplacement des pièces devraient être effectués par un technicien qualifié.
- Posez les boulons de la manière spécifiée. Ne les serrez pas avant d'avoir entièrement terminé l'assemblage du fauteuil.
- Ne jetez pas l'emballage avant de vous assurer d'avoir toutes les pièces et l'équipement requis.
- Les enfants doivent être surveillés par un adulte durant l'usage de ce fauteuil.
- Conservez ces instructions d'assemblage pour consultation ultérieure.

**IMPORTANT :** Lisez attentivement ce guide et conservez-le à des fins de consultation ultérieure.


**4** PRODUIT N° RMS633G | MODÈLE N° 088-2217-6


**1**   
 Bras droit - 1  
 RMS633G-CS01-3


**2**   
 Bras gauche - 1  
 RMS633G-CS01-2


**3**   
 Traverse - 1  
 RMS633G-CS08-1


**4**   
 Équerre - 1  
 RMS633G-CS14-1-SV01


**5**   
 Siège - 1  
 RMS633G-CS11-1


**6**   
 Support - 1  
 RMS633G-CS14-1-SV02


**7**   
 Coussin du dossier - 1  
 61R633GX00001BA


**8**   
 Coussin du siège - 1  
 61R633GY00001BA

**A**   
 Boulon M6x15 mm - 4  
 17C33A0706001YX

**B**   
 Boulon M6x30 mm - 4  
 17C02A0710002YX

**C**   
 Boulon M8x40 mm - 4  
 17C01A0814001YX


**D**   
 Boulon M8x45 mm - 4  
 17C01A0816071YX

**E**   
 Rondelle D6,5xD13X1,0 mm - 4  
 17FA05040301-YX

**F**   
 Rondelle D8,5xD17x1,6 mm - 12  
 17FA08060601-YX

**G**   
 Rondelle 50x50x.4,5 mm - 2  
 17EF1201-----23

**H**   
 Contre-écrou M8x1,25 mm - 4  
 17D03A040401-YX

Outils 

**ATTENTION!**

- Il est essentiel que le fauteuil soit installé d'aplomb.
- Ne placez pas ce produit en dessous de câbles électriques.
- Tenez les enfants éloignés durant l'assemblage.
- Ce produit contient de petites pièces que les enfants pourraient avaler.
- Prenez soin de ne pas vous pincer ou coincer les doigts là où c'est possible.
- Ne tentez pas d'assembler ce fauteuil si des pièces manquent.

**Laissez-nous vous aider!**



**NE RETOURNEZ PAS CE PRODUIT AU MAGASIN. APPELÉZ-NOUS D'ABORD!  
1 888 670-6684**

Si vous avez des questions concernant ce produit, désirez de l'aide concernant la garantie ou si des pièces manquent ou sont endommagées, appelez sans frais notre service d'aide à la clientèle. Nous sommes là pour vous aider!

**IMPORTANT :** Veuillez lire et vous assurer de comprendre ce guide avant d'assembler le produit. Assurez-vous d'avoir toutes les pièces avant de commencer. Comparez les pièces avec celles de la liste fournie dans l'emballage. Si une pièce manque, ou si vous avez des questions, appelez (sans frais) le service à la clientèle au 1 888 670-6684.

Placez les pièces devant vous dans une aire dégagée. Retirez tout le matériel d'emballage et mettez-le dans la boîte. Ne jetez pas le matériel d'emballage avant d'avoir terminé l'assemblage. Lisez chaque étape attentivement avant de commencer l'assemblage des pièces et assurez-vous de bien comprendre chaque étape. S'il vous manque une pièce, appelez-nous sans frais pour de l'aide au 1 888 670-6684.

Requis pour l'assemblage :




Clé dynamométrique I + vis 6 pans II

Clé dynamométrique I + vis 6 pans III

Deux personnes

**Étape 1****Nécessite : pièces 5, 6, A et E**


Placez l'assise sur une surface non rugueuse, telle qu'un tapis, en la retournant dans le sens inverse. Fixez la traverse **6** à l'assise **5** à l'aide des boulons **A** et des rondelles **E**.

**Étape 2****Nécessite : pièces 1, 2, 3, et B**

Fixez la traverse **3** au bras droit **1** et au bras gauche **2** à l'aide des boulons **B**. Ne serrez pas les boulons.

Remarque :

Pour assembler le fauteuil correctement, les indications « L » et « R » sur les bras (**1** et **2**), doivent aller dans le sens illustré à l'étape 2.







### Étape 3

Nécessite : pièces 1, 2, 4, C et F


Fixez l'équerre 4 aux bras 1 et 2 à l'aide des boulons C et des rondelles F.  
Ne serrez pas les boulons.



### Étape 4



Nécessite : pièces 4 et 5

Positionnez le dossier 5 sur l'équerre 4.




**Étape 5****Nécessite : pièces 4, 6, D, F, G, H, I, II, III, et IV**

Reliez le support **6** à l'équerre **4** à l'aide des boulons **D**, des rondelles (**F** et **G**), et des contre-écrous **H**. Assurez-vous d'avoir entièrement serré les boulons en vous servant des clés **I**, **II**, **III**, et **IV**.

**Étape 6****Nécessite : pièces 7 et 8**

Placez les coussins **7** et **8** sur le fauteuil. Retenez-les en place à l'aide des pinces en plastique.



**ATTENTION!**

- Vérifiez les vis et écrous périodiquement pour vous assurer qu'ils tiennent bien et resserrez-les s'il y a lieu.
- Pour démonter le fauteuil, suivez les étapes de l'assemblage dans l'ordre inverse. Démontez toujours l'article entièrement. Un fauteuil partiellement démonté n'est pas assez solide pour résister au vent et aux intempéries, d'où le risque de l'endommager ou de causer des dommages.
- Nettoyez le fauteuil avec de l'eau et du savon doux. Rincez-le et attendez qu'il soit sec avant de le réassembler.

- Lavez l'armature et le rotin avec de l'eau et du savon doux, rincez-les et séchez-les complètement. N'utilisez pas de javellisant, d'acide ou autres solvants sur toute composante de l'armature ou sur le rotin.
- Vous pouvez laver les coussins sur le dessus uniquement avec de l'eau et un savon doux, ou utiliser un produit moussant du commerce pour meubles rembourrés si nécessaire. Si vous les lavez, rincez-les et suspendez-les pour sécher. Ne les lavez pas et ne les séchez à la machine.
- Nous vous conseillons de recouvrir votre fauteuil d'une housse lorsque vous ne l'utilisez pas.
- Inspectez et serrez régulièrement les boulons ou attaches pour vous assurer que votre fauteuil est sécuritaire.
- Afin de prolonger la durée et la beauté de votre fauteuil, nous vous recommandons de la ranger dans un endroit sec et abrité durant la saison morte.

Dimensions (long. x larg. x H.)

31 7/8 x 28 9/16 x 33 7/8"

81 x 72,5 x 86 cm

Poids

34 lb 10 oz

15,7 kg

Cet article CANVAS<sup>MC</sup> comporte une garantie de trois (3) ans sur le cadre contre les défauts de fabrication et de matériaux et une garantie de un (1) an sur les autres pièces. Distribution Trifeuil consent à remplacer le produit défectueux sans frais lorsqu'il est retourné par l'acheteur original, accompagné de la preuve d'achat, au cours de la période de garantie convenue. Exclusion : usure ou bris causés par un usage abusif ou inapproprié.